

INSTRUCTION MANUAL**ENGLISH ENG****STAINLESS STEEL WHISTLING KETTLE****MODEL: ORK-0370, ORK-0371 ORK-0372, ORK-0373 ORK-0374**

Dear customers! Thank you for purchasing ORION products. Before operation, please read this instruction manual. Save it for future reference.

INTRODUCTION

ORION kettle with whistle is made of high quality stainless steel, has a classic design and is designed to heat and boil water. When water boils kettle makes a nice whistle.

Stainless steel kettles have a modern aesthetic look, are durable and safe to use. This material has a high ecological purity, is resistant to acids and alkalis and is easy to clean.

If you want your kettle to serve you for many years, you need to follow the simple rules for operation and maintenance.

SAFETY MEASURES

1. Read this instruction manual before using the device.
2. This device must not be used by children or persons with diminished mental, physical or sensorial capacities, unless said people have received specific assistance or instruction for using the device by a person responsible for their safety who is fully aware of the dangers involved.
3. The device must not be used if it was damaged. Have the device checked by an expert or the customer service.
4. Do not repair the appliance by yourself.
5. Place the device on a stable surface.
6. Attention! Do not let children play with the device or packaging materials!
7. Keep out of the reach of children.
8. To avoid damage and injury, use only the accessories and/or removable parts that are supplied or recommended by the manufacturer.
9. Do not cover the device.
10. The device heats up during operation. Wait until the device cools down. Only then you can begin to clean the device or place it for storage.
11. Avoid any contact with the hot parts of the device. Always take the kettle by the handle.
12. While boiling and/or a short time after switching off the device, avoid any contact with steam coming out of the spout.
13. Do not leave children / babies unattended near operating device. This is very dangerous!
14. Ensure that there is always a lid on the top of the kettle. And never remove it during operation. Otherwise, this may cause a burn.
15. The device is designed for boiling water.
16. Use the device only for the purposes for which it is intended.
17. The device is intended for domestic/household use.
18. Save this instruction manual for future reference.

WARNING! NOT FOLLOWING SAFETY MEASURES CAN CAUSE INJURIES, BURNS AND FIRE!

CHARACTERISTICS

- Capacity: 2.8L (ORK-0370), 3.1L (ORK-0371/ORK-0372/ORK-0373/ORK-0374).
- Material: Stainless steel/heat-resistant plastic.
- Suitable for the following types of cookers: electric, gas, ceramic, induction cookers.
- Ergonomic design.
- The handle and lid are made of heat-resistant plastic.
- Capsulated bottom for quick and even heat distribution.
- Not suitable for use in a dishwasher.

Model	Capacity / L	Bottom diameter Ø/ cm	Net weight/ kg	Gross weight/ kg	Color	Box size/ cm
ORK-0370	2.8	20.3	0.95	1.4	Stainless steel	20.5x20.5x22.5
ORK-0371	3.1	22.5	1.05	1.4	Red	22.5x22.5x23
ORK-0372	3.1	22.5	1.05	1.4	Graphite	22.5x22.5x23
ORK-0373	3.1	22.5	1.05	1.4	Purple	22.5x22.5x23
ORK-0374	3.1	22.5	1.05	1.4	Stainless steel	22.5x22.5x23

DETAILS

1. Whistle
2. Spout open button
3. Handle
4. Removable lid
5. Body

BEFORE FIRST USE

- Please read these instructions before operating. Save it for later use.
- Before first use, remove all labels and packaging materials from the surface of the kettle/inside the kettle.
- Wash the kettle with hot water and a mild detergent, rinse and wipe dry.
- Boil a full kettle of water twice. Pour water. The kettle is ready to use.

HOW TO USE

1. Open the lid.
2. Fill the kettle with the required amount of water and close the lid (Do not pour water into the kettle through the spout).
3. Put the kettle on the burner. The diameter of the burner shall not exceed the diameter of the bottom of the kettle.
4. Turn on the cooker. When the water in the kettle boils, you will hear the sound of whistle.
5. Turn off the cooker and remove the kettle from the burner.

Attention! Do not place empty kettle on the hot/working burner!

CLEANING AND STORAGE

- Before cleaning, make sure your device is fully cooled.
- Pour remaining water and wipe gently with a damp cloth, then wipe dry.
- Do not use abrasive cleaners and metal sponges.
- Do not wash the device in the dishwasher.
- We recommend to clean the device from scale regularly. Use special cleaning agents.
- Keep it (preferably in the original package) in dry place, out of reach of children.

Note: to extend the service life of your device and to avoid corrosion, always pour the remaining water from the kettle and wipe it dry.

PACKAGE CONTENTS

- | | |
|-----------------------|-------|
| 1. Whistling kettle | 1 pc. |
| 2. Removable lid | 1 pc. |
| 3. Instruction manual | 1 pc. |
| 4. Warranty card | 1 pc. |

Note: DOES NOT CONTAIN HAZARDOUS SUBSTANCES

Subject to change without notice

Extra information you can find on ORION company web-site www.orion.ua

If you have any questions or suggestions, contact us by E-mail support@orion.ua

Manufacturer: Orion China Ltd., 1733 Lianhua St., apt. 506-509, Shanghai, People's Republic of China, 201103
Made to order: Orion Electronics Ltd. (Hungary)

